



# Flow Rates in lbs/acre for RED ROLLER

Dec-98

**Valmar 1655, 2055, 3255 IM, 245 PT, 245TM, 242TM, 1255 PT, 5500 PT, 6600/7600 PT**

Red roller - 1/4 in. gap

Fertilizer	DENSITY LB/CFT	GEARBOX SETTING																GEARBOX INPUT RATIO
		NO. 1		NO. 2		NO. 3		NO. 4		NO. 5		NO. 6		NO. 7		NO. 8		
		A	B	A	B	A	B	A	B	A	B	A	B	A	B	A	B	
Sulpher-Tiger 90	76	7.6		8.0	8.4	8.8	9.2	9.7	10.2	10.7	11.2	11.8	12.4	12.9	13.7	14.2	15.1	<b>ULTRA LOW RATIO</b> Implement Mount 1655, 2055, 3255 
Sulfer 95 (0-0-0-95)	58	7.0		7.4	7.8	8.2	8.6	9.0	9.5	9.9	10.4	10.9	11.5	12.0	12.7	13.2	14.0	
Sulpher-Tiger 90	76	15		16	17	18	18	19	20	21	22	23	25	26	27	28	30	<b>LOW RATIO</b> Implement Mount 1655, 2055, 3255 
Sulfer 95 (0-0-0-95)	58	14		15	15	16	17	18	19	20	21	22	23	24	25	26	28	





USE THIS CHART AS A GUIDE ONLY, CALIBRATE YOUR APPLICATOR.

## Flow Rates in lbs/acre for RED ROLLER

Dec-98

Valmar 1655, 2055, 3255 IM, 245 PT, 245TM, 242TM, 1255 PT, 5500 PT, 6600/7600 PT

Red roller - 1/4 in. gap

Fertilizer	DENSITY LB/CFT	GEARBOX SETTING																GEARBOX INPUT RATIO
		NO. 1		NO. 2		NO. 3		NO. 4		NO. 5		NO. 6		NO. 7		NO. 8		
		A	B	A	B	A	B	A	B	A	B	A	B	A	B	A	B	
Sulpher-Tiger 90	76	30		32	34	36	37	39	41	43	45	47	50	52	55	57	61	<p style="text-align: center;"><b>MEDIUM RATIO</b> Implement Mount 1655, 2055, 3255</p>  <p style="text-align: center;">19 T 27 T</p> <hr/> <p style="text-align: center;">1255 PT &amp; 245 PT</p>  <p style="text-align: center;">19 T 27 T</p>
Sulfer 95 (0-0-0-95)	58	28		30	31	33	35	36	38	40	42	44	46	48	51	53	56	
Sulpher-Tiger 90	76	61		64	67	71	74	78	82	86	90	94	99	104	110	114	121	<p style="text-align: center;"><b>HIGH RATIO</b> Implement Mount 1655, 2055, 3255</p>  <p style="text-align: center;">12 T 34 T</p> <hr/> <p style="text-align: center;">1255 PT &amp; 245 PT</p>  <p style="text-align: center;">12 T 34 T</p>
Sulfer 95 (0-0-0-95)	58	56		60	62	66	69	72	76	80	84	88	92	97	102	106	113	

USE THIS CHART AS A GUIDE ONLY, CALIBRATE YOUR APPLICATOR.